

ALR Series Electronic Linear Actuators

1 INTRODUCTION

The ALR Series Electronic Linear Integral Actuators are designed to mount directly to the engine's fuel pump in place of the electronic stop solenoids. The ALR Series high-quality construction is designed for high-temperature operation. GAC's unique linear electromechanical technology provides proportional actuator movement based on actuator coil current. GAC uses precision linear ball bearings instead of bushings giving the ALR Series a minimum number of moving parts, improving response, precision and reliability.

The ALR Series Actuator is designed to replace the OEM equipped shut down solenoid. To properly install the ALR actuator, a precise measurement must be obtained from the removed OEM equipped shutdown solenoid. Before beginning the installation of the ALR actuator, remove all DC battery power from the equipment being serviced.



Section 2 lists the common engine models ALRs are used with. See your GAC representative for other makes and models.

2 APPLICATIONS - ALL MODELS

NOTE Check engine dimensions before selecting or installing an ALR as alterations made to factory engines may impact ALR fit.

ENGINE FAMILY	ENGINE MODEL	ACTUATOR MODEL	ENGINE FAMILY	ENGINE MODEL	ACTUATOR MODEL	ENGINE FAMILY	ENGINE MODEL	ACTUATOR MODEL
CATERPILLAR			ISUZU			MITSUBISHI		
C Series	C2.2T	ALR190-P04 -12 or -24	C-Series	2CA	ALR190-Y04 -12 or -24	L-Series	L2E	ALR190-M04 -12
	C3.4			L3E				
	C1.5	ALR160-S04 -12 or -24		S3L-Series	S3L			
	C1.7	ALR190-P403 -12 or -24			S3L2			
		S4L						
		S4L2						
PERKINS			YANMAR					
Perkins	404D-15 404D-22	ALR190-P04 -12 or -24 or ALR160-S04 -12 or -24	KUBOTA			TNV- and TNE-Series	2TNV70	ALR190-Y04 -12 or -24
	403D-15 403D-15T	ALR190-P403 -12 or -24	Super 5 Series	D905	ALR190-K04 -12 or -24		3TNV70	
				D1005			3TNV76	
		D1105		3TNV82A				
		D1105-T		3TNV84 3TNV84T				
		V1305		3TNV88				
SHIBAURA (PERKINS)			V3 Series	V1505, -T	ALR190-KV03 -12 or -24		4TNV84	
Shibaura (Perkins)	N843-C, N844L-C, N844LT-C	ALR160-S04 -12 or -24 ALR190-P04 -12 or -24		V3300 V3600 V3600T V3800			4TNV94L	
				V2003 V2203 V2403			4TNV88	
				V2607 V3007 V3307			4TNV98 4TNV98T	
			03 Series		ALR190-KV07 -12 or -24		2TNE	
			07 Series		ALR190-KV07 -12 or -24		3TNE	
			DI-T	V3800DI-T	ALR190-KV03DIT -12 or -24		4TNE	




3 SPECIFICATIONS

ELECTRICAL		
	190-I, 190-K, 190-M, 190-P, 190-Y	160-S
Operating Voltage	12 or 24 V DC	12 or 24 V DC
Normal Operating Current	3.2 A @12 V DC 1.6 A @24 V DC	4.8 A @12 V DC 2.4 A @24 V DC
Maximum Current Continuously Rated	5.0 A @12 V DC 2.5 A @24 V DC	7.5 A @12 V DC 3.8 A @24 V DC
Coil Resistance (12 V DC) (24 V DC)	1.8 ± 0.2 Ω 6.3 ± 0.2 Ω	1.5 ± 0.1 Ω 6.0 ± 0.2 Ω
Connection 16 AWG	(0.8 mm ²) leads	(0.8 mm ²) leads
ENVIRONMENTAL		
Operating Temperature Range	-40 to +200 °F [-40 to 95 °C]	
Relative Humidity	up to 100 %	
Vibration	± 4 g, 25 to 100 Hz	
Shock	20 g Peak, 11 ms	
All Surface Finishes	Fungus Proof and Corrosion Resistant	
Sealing	Oil, Water, and Dust Resistant	


PERFORMANCE		
MODEL	OPERATING STROKE	RESPONSE TIME (1 - 90 %)
160-S	0.51 in (13.0 mm)	1-12 mm 35 ms
190-I	0.55 in (14.0 mm)	2-12.6 mm 35 ms
190-K	0.49 in (12.5 mm)	1-12 mm 35 ms
190-M	0.54 in (13.9 mm)	1-13 mm 35 ms
190-P	0.42 in (10.4 mm)	1-9 mm 35 ms
HARDWARE		
CONNECTOR TYPE		MODELS
Spade		ALR190-I03
Packard	ALR160-S04, ALR190-I03, ALR190-K04, ALR190-KV03, ALR190-KV07, ALR190-KV03DIT, ALR190-M04, ALR190-P04, ALR190-P403, ALR190-Y04	
PHYSICAL		
Weight		1.3 lbf [0.59 kgf]

4 DIAGRAMS

ALR160-S




ALR190-P04




Dimensions: [mm]
in


ALR190-P403




ALR190-I




ALR190-M




ALR190-Y



ALR190-K04



ALR 190-KV03, ALR 190-KV03DIT, ALR190-KV07



5 ALR INSTALLATION INSTRUCTIONS



1. The engine should be equipped with an independent shut down device to prevent overspeed, which can cause equipment damage or personal injury.
2. Do not attempt this installation with engine running or serious damage may occur to the equipment or personnel.
3. **Before beginning the installation of the ALR actuator, remove all DC battery power from the equipment being serviced.**

NOTE

The ALR190-M04 is the only actuator that includes shims.

INSTALLATION PROCEDURE FOR ALR190-M04




The ALR190-M unit must be adjusted for proper operation. If the installation procedure is not followed, damage to the actuator and or injection pump is possible.

1. Index mark the OEM shutdown solenoid directly behind the locknut with a marker or scribe before loosening the locknut. This mark is important. A precise measurement (depth micrometer) will be taken after shutdown solenoid is removed from the injection pump housing.
2. Remove the wiring harness and loosen the solenoid locknut. Clean the area from dirt or grease. Loosen and remove solenoid from the injection pump housing using standard service cautions.
3. Move locknut on shutdown solenoid back to previously indexed mark (Step 1) and measure distance from the front side of locknut (side that was previously against injection pump housing) to the end of shutdown solenoid shaft. Record this measurement. The more precise this measurement (depth micrometer) the more precise the ALR actuator will perform.
4. Use the locknut from the old shut off solenoid and position it on the new ALR actuator the same distance as the old solenoid (Step 2). *Shims are included with this actuator if needed to set position.
5. Clean threads and mounting surface of the ALR actuator. Install ALR into injection pump housing (no sealant required) until locknut is flush with injection pump housing. If resistance is felt, remove ALR and inspect threads for dirt or burrs. Also use a clean lint free rag to clean injection pump internal threads. A small amount of clean engine oil can be applied if desired. When locknut is flush with injection pump housing tighten nut down.
6. Install wiring harness, start engine, adjust governor speed controller following the GAC manual.

STEP 2

Use locknut from old shutoff actuator and position the locknut on the new actuator at the same distance as "X".



STEP 1

With the locknut in the exact same position as it was installed in the pump, measure and record this dimension.

The more precise the measurement the more precise the ALR actuator will perform. Use this dimension to set the position of the ALR actuator.

5 ALR INSTALLATION INSTRUCTIONS (CONTINUED)

INSTALLATION PROCEDURE FOR ALR190-I, 190-P, AND ALR160-S

1. The actuator is installed in place of the engine's stop solenoid. Remove the solenoid by first disconnecting the electrical leads at the connector.
2. Remove the wiring harness and loosen the solenoid locknut. Clean the area from dirt or grease. Loosen and remove solenoid from the injection pump housing using standard service cautions.
3. Discard OEM installed shutdown solenoid and locknut. Locknut is NOT REQUIRED for the ALR installation.
4. Clean threads and mounting surface of the ALR actuator. Install ALR into injection pump housing (no sealant required) until actuator package is flush with injection pump housing.
 - If resistance is felt, remove ALR and inspect threads for dirt or burrs. Use a clean lint free rag to clean injection pump internal threads. A small amount of clean engine oil can be applied if desired.
 - When actuator is flush with injection pump housing, hand tighten only. After engine has reached operating temperature recheck tightness (use caution, unit will get hot), if required re-tighten by hand only.
5. Install wiring harness, start engine, adjust governor speed controller following the GAC manual.

INSTALLATION PROCEDURE FOR 190-K AND 190-Y

1. The actuator is installed in place of the engine's stop solenoid. Remove the solenoid by first disconnecting the electrical leads at the connector.
2. Cover and secure the engine harness leads as they are no longer needed.
3. Remove the two screws that attach the solenoid to the pump face. Save the screws and O-ring. They will be reused when attaching the actuator.
4. Install the o-ring into the counter bore on the pump face.
5. Install the actuator using the solenoid screws.
6. Attach the actuator leads from the speed control unit.

6 ALR TROUBLESHOOTING

TROUBLE SHOOTING

If the actuator fails to move to full fuel, make the following tests:

1. Measure battery voltage at the controller (see specification for the operating voltage).
2. Check linkage. Manually operate linkage to ensure it is not sticking or binding.

If the actuator fails to move, make the following tests:

1. Measure the coil resistance between the actuator leads (see specification for resistance).
2. Measure the resistance between one lead of the actuator and the housing of the actuator. It should be infinity.
3. Energize the actuator to full fuel by following the procedure in the control unit publication. If the actuator does not move, it is defective.

If problems occur, contact your GAC representative or GAC at www.governors-america.com